

Fragdet

FRAGMENTATION DETECTION AND ANALYSIS SOFTWARE

GMV's **Fragdet** COTS software is a software application for **detecting in-orbit fragmentations** of objects orbiting the Earth. It is able to detect two different types of fragmentations: a fragmentation due to a **collision** between two objects or the **explosion** of an object itself. The fragmentation detection process is assessed trying to group newly detected objects into potential fragmentations events and assigning the parent (explosion) or parents (collision) to each fragmentation.

The **in-orbit fragmentation detection process** performed by **Fragdet** consists of the following steps:

- **Detection of fragmentations** through a **short-term analysis** based on whether several newly detected objects coincide in space and time in the recent past
- Characterisation of fragmentation as **explosion or collision**
- Identification of **progenitor/s**
- Use of **long-term statistical methods** to include newly detected objects as **new fragments of an existing fragmentation cloud**
- **Fragmentation simulation** with NASA break-up model for generation of expected increase in space debris spatial density (below observable size) as well as the estimated percentage of objects detected
- **Fragmentation plots** generation (evolution of number of fragments over time, Gabbard diagram)

The process of **in-orbit fragmentation detection** consists of the following steps:

- Backward propagation of orbital information of newly detected
- Detection of conjunctions in the past among newly detected objects and also past objects
- Grouping of newly detected objects in fragmentations based on their participation in conjunctions in the past among them
- Computation of time and location of fragmentation based on the conjunctions in the past involving the fragments of a detected fragmentation
- Identification of progenitor objects of each fragmentation based on the detection of conjunctions between existing objects and newly detected objects

Additionally, **Fragdet** counts with a fragmentation simulation component able to generate a cloud of fragments generated in a collision or explosion together with the corresponding orbital information. This feature is very useful for fragmentation simulation and validation/testing purposes.

In terms of processing experience, **Fragdet** has been used in the following operational scenarios:

- **GMV** for in-house analyses of several real fragmentations (e.g. recent Indian Anti-Satellite test), as for instance, in the frame of its participation in Global Sentinel events through the Spanish Army
- **EU-SatCen** for the generation of testing data of the EUSST SatCen Web Portal

In terms of run-time performance, **Fragdet** is able to perform a fragmentation analysis of a fragmentation with 500 new objects on top of a background population of 10000 objects in less than 45 minutes running in a single modern core

As end user products, **Fragdet** generates the following products:

- **Fragmentation data** file, containing all the information of the fragmentation in the form of a CCSDS-like fragmentation warning message in XML format



CONTACT
sst@gmv.com



```

[?xml version="1.0" encoding="UTF-8" standalone="yes"?]
<fwm id="FWM_VERS" version="1.0">
  <header>
    <COMMENT>FWM generated by Focus</COMMENT>
    <ORIGINATOR>Focus-FragSimApp</ORIGINATOR>
    <GENERATION_EPOCH>2018-04-15T20:34:13.233Z</GENERATION_EPOCH>
    <MESSAGE_ID>N/A</MESSAGE_ID>
  </header>
  <body>
    <FragmentationMetadataData>
      <FRAG_TYPE>COLLISION</FRAG_TYPE>
      <FRAG_EPOCH>2015-12-01T04:35:49.136Z</FRAG_EPOCH>
      <FRAG_DET_EPOCH>2015-12-01T04:35:49.136Z</FRAG_DET_EPOCH>
      <NUMBER_OF_FRAGMENTS>28</NUMBER_OF_FRAGMENTS>
      <FRAG_LOCATION>
        <REF_FRAME>ITRF</REF_FRAME>
        <POSITION_X units="km">27241.20289216886</POSITION_X>
        <POSITION_Y units="km">-32592.940828812312</POSITION_Y>
        <POSITION_Z units="km">4122.416806005868</POSITION_Z>
        <LONGITUDE units="deg">-50.111098650928554</LONGITUDE>
        <LATITUDE units="deg">5.5486110142255777</LATITUDE>
        <ALTITUDE units="km">38299.65894466408</ALTITUDE>
      </FRAG_LOCATION>
      <REL_VELOCITY units="km/s">0.8275212072434946</REL_VELOCITY>
      <ENERGY_TO_MASS_RATIO units="MJ/kg">0.017119783710943273</ENERGY_TO_MASS_RATIO>
      <DETECTED_PERCT_NUMBER>100.0</DETECTED_PERCT_NUMBER>
      <DETECTED_PERCT_MASS>100.0</DETECTED_PERCT_MASS>
      <DETECTED_PERCT_AREA>100.0</DETECTED_PERCT_AREA>
      <FRAG_MODEL>NASA BREAKUP MODEL FOR EVOLVE 4.0</FRAG_MODEL>
      <SPATIAL_DENSITY_DATA>
        <SPATIAL_DENSITY_RECORD>
          <RADIAL_DISTANCE units="km">18999.137</RADIAL_DISTANCE>
          <DECLINATION units="deg">5.00000000000001</DECLINATION>
          <RAAN units="deg">5.0</RAAN>
          <SPATIAL_DENSITY_INCREASE>1.0228214083052085E-12</SPATIAL_DENSITY_INCREASE>
        </SPATIAL_DENSITY_RECORD>
        <SPATIAL_DENSITY_RECORD>
          <RADIAL_DISTANCE units="km">18999.137</RADIAL_DISTANCE>
          <DECLINATION units="deg">5.00000000000001</DECLINATION>
          <RAAN units="deg">5.0</RAAN>
          <SPATIAL_DENSITY_INCREASE>1.5910180493798663E-12</SPATIAL_DENSITY_INCREASE>
        </SPATIAL_DENSITY_RECORD>
      </SPATIAL_DENSITY_DATA>
    </FragmentationMetadataData>
  </body>
</fwm>

```

Figure 1: Example of CCSDS-like fragmentation warning message generated by *Fragdet*